
## DIG HINGED FRONT DOOR ASSEMBLY

## cossiga



## DTG FRONT DOOR KIT

MODEL	NUMBER OF DOORS AND PART CODE	
	No. Doors	PART CODE
DTG6	1	F93-908
DTG9	2	F93-904
DTG12	2	F93-905
DTG15	2	F93-913





folded edge to outside of frame

REMOVE BOTTOM CLEAR PANEL

Undo screws from brackets. Remove the
acrylic front panel and brackets and discard.



PLACE TEMPLATE - DRILL AND TAP HOLES

Make sure cabinet is level on the floor with a sprit level.

Adjust the stabilizers around the feet. Drill 5.2mm holes with the template hard on top or bottom and folded edge facing the frame. Tap holes with M6 Tap.





ATTACH HINGE TO FRAME Attach the hinge to the frame to test fitting. Loosely put all 4 screws in before tightening - this allows for tolerance

REMOVE AND ATTACH HINGE TO DOOR Once you are satisfied all hinges are fitting to frame correctly, remove the hinges from the frame for fitting to door. Remove the outer part of the hinge. This part will go on the on the inside of the door.







**OUTSIDE** 

**INSIDE** 

ATTACH HINGE TO DOOR Attach the hinges to the acrylic door by replacing outer hinge part.

ATTACH DOOR TO FRAME Lift door and attach to to frame ( 2 people required ) screw in outside and inside screws.



ATTACH DOOR HANDLES

Place plastic washer, metal washer and screw in.