



Applicable models:
DTGHT6
DTGHT9

Replacement
Fan Part
(S16-916)




1. Unscrew the shelf LED plugs from the wall



2. Remove the shelves by lifting them up before pulling them out







- 3.** Remove the screws which attach the inner panel to the cabinet



- 4.** To remove the inner panel, lift up before pulling the bottom end out and down




- 5.** Remove the 4 screws which attach the fan plate to the cabinet




- 6.** Pull the fan out of the cabinet and remove the screws that hold the fan to the fan plate







7 ■ Unplug the wires from the terminals on the fan



8 ■ Remove the old fan and have the new fan ready to be installed




9 ■ Plug the wires onto the terminals of the new fan and screw the new fan onto the fan plate




10 ■ Screw the fan plate back onto the cabinet





11. Install the inner panel by lifting the top end up before pushing the bottom end inwards



12. Screw in the panel screws



13. Re-install the shelves, making sure they are level and inserted into the frame correctly



14. Screw the LED plugs back on

